

1. Open T-Plus software.
2. Select appropriate pump from list.
3. Set pump to Serial Mode (Remote is default)
4. Open control panel
5. Insert unknown window from tools menu
6. Select Insert unknown window at the bottom of control panel
7. Unknown window dialog box opens.
8. Select Numeric and enter Nr. 358
9. Label as Tip Seal
10. Click the new "Tip Seal" option that now appears on the control panel. Note down hour value.
11. Now reset the counter by entering 000000
12. Click Send
13. Return pump to Remote if necessary.